





VDI


COMMON DRIVE COUPLINGS FOR *LIVE* VDI TOOLS




Coupling to DIN 5482




Coupling to DIN 5480




IT Coupling



Coupling bevel gear



Coupling to DIN 1809



MT (Baruffaldi type)